## SITOP

## 

## KOMATSU PC1100-6 PC1100SP-6 PC1100LC-6

MACHINE MODEL SERIAL NUMBER

PC1100-6 10001 and up PC1100SP-6 10001 and up PC1100LC-6 10001 and up

- This shop manual may contain attachments and optional equipment that are not available
  in your area. Please consult your local Komatsu distributor for those items you may
  require. Materials and specifications are subject to change without notice.
- PC1100-6 mount the SAA6D170-2 engine.
   For details of the engine, see the 6D170-2 Series Engine Shop Manual.

## **CONTENTS**

		No. of page
01	GENERAL	. 01-1
10	STRUCTURE AND FUNCTION	10-1
20	TESTING AND ADJUSTING	20-1
30	DISASSEMBLY AND ASSEMBLY	30-1
40	MAINTENANCE STANDARD	<b>.</b> 40-1
90	OTHERS	90-1