

SHOP

MANUAL

KOMATSU

PC1100-6

PC1100SP-6

PC1100LC-6

MACHINE MODEL

SERIAL NUMBER

PC1100-6

10001 and up

PC1100SP-6

10001 and up

PC1100LC-6

10001 and up

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- PC1100-6 mount the SAA6D170-2 engine.
For details of the engine, see the 6D170-2 Series Engine Shop Manual.

CONTENTS

| | No. of page |
|--|-------------|
| 01 GENERAL | 01-1 |
| 10 STRUCTURE AND FUNCTION | 10-1 |
| 20 TESTING AND ADJUSTING | 20-1 |
| 30 DISASSEMBLY AND ASSEMBLY | 30-1 |
| 40 MAINTENANCE STANDARD | 40-1 |
| 90 OTHERS | 90-1 |