

SHOP

MANUAL

**KOMATSU**

**PC128UU-1**

**PC128US-1**

# CONTENTS

	No. of page
<b>01 GENERAL</b> .....	01-1
<b>10 STRUCTURE AND FUNCTION</b> .....	10-1
<b>20 TESTING AND ADJUSTING</b> .....	20-1
<b>30 DISASSEMBLY AND ASSEMBLY</b> .....	30-1
<b>40 MAINTENANCE STANDARD</b> .....	40-1
<b>90 OTHERS</b> .....	90-1