

# Shop Manual

HYDRAULIC  
EXCAVATOR

**PC2000-8**

SERIAL NUMBERS 20001 and up

**KOMATSU**

## Table of contents

00 Index and foreword	
Index	SEN01609-22
Composition of shop manual .....	2
Table of contents.....	4
Foreword and general information	SEN01610-04
Safety notice .....	2
How to read the shop manual.....	7
Explanation of terms for maintenance standard .....	9
Handling of electric equipment and hydraulic component .....	11
Handling of connectors newly used for engines .....	20
How to read electric wire code.....	23
Precautions when carrying out operation .....	26
Method of disassembling and connecting push-pull type coupler .....	29
Standard tightening torque table.....	32
Conversion table.....	36
01 Specification	
Specification and technical data	SEN01612-04
Specification drawings .....	2
Specifications.....	6
Weight table .....	10
Table of fuel, coolant and lubricants .....	16
10 Structure, function and maintenance standard	
Engine and cooling system	SEN01614-01
Radiator and oil cooler.....	2
PTO .....	4
PTO lubrication system.....	6
Power train	SEN01615-01
Power train.....	2
Swing machinery .....	4
Swing circle.....	6
Final drive .....	8
Sprocket.....	10
Undercarriage and frame	SEN01616-01
Track frame.....	2
Idler.....	4
Carrier roller.....	6
Track roller .....	7
Track shoe .....	8
HIC system .....	13