

SHOP

MANUAL

KOMATSU

PC200, 200LC-6 PC220, 220LC-6

MACHINE MODEL

SERIAL NUMBER

PC200, 200LC-6

80001 and up

PC220, 220LC-6

50001 and up

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- PC200-6 mount the S6D95L-1 engine;
PC220-6 mount the SA6D95L-1 engine.
For details of the engine, see the 95 Series Engine Shop Manual.

CONTENTS

	No. of page
01 GENERAL	01-1
10 STRUCTURE AND FUNCTION	10-1
20 TESTING AND ADJUSTING	20-1
30 DISASSEMBLY AND ASSEMBLY	30-1
40 MAINTENANCE STANDARD	40-1

020506