

SHOP MANUAL

KOMATSU

PC300, 300LC-7

PC350, 350LC-7

| MACHINE MODEL | SERIAL NUMBER |
|---------------|---------------|
|---------------|---------------|

| | |
|----------------|---------------------|
| PC300-7 | 40001 and up |
|----------------|---------------------|

| | |
|------------------|---------------------|
| PC300LC-7 | 40001 and up |
|------------------|---------------------|

| | |
|----------------|---------------------|
| PC350-7 | 20001 and up |
|----------------|---------------------|

| | |
|------------------|---------------------|
| PC350LC-7 | 20001 and up |
|------------------|---------------------|

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- PC300, 300LC, PC350, 350LC-7 mount the SAA6D114E engine. For details of the engine, see the 114 Series Engine Shop Manual.

CONTENTS

| | No. of page |
|--|-------------|
| 01 GENERAL | 01-1 |
| 10 STRUCTURE, FUNCTION AND MAINTENANCE STANDARD | 10-1 |
| 20 TESTING AND ADJUSTING | 20-1 |
| 30 DISASSEMBLY AND ASSEMBLY | 30-1 |
| 90 OTHERS | 90-1 |