

# SHOP MANUAL



# PC35R-8

# PC45R-8

**HYDRAULIC EXCAVATOR**

SERIAL NUMBER

**PC35R-8 F20001** and up

**PC45R-8 F20001** and up

**KOMATSU**

# CONTENTS

<b>10 STRUCTURE AND FUNCTION .....</b>	<b>10-1</b>
<b>20 TESTING AND ADJUSTING.....</b>	<b>20-1</b>
<b>30 REMOVAL AND INSTALLATION .....</b>	<b>30-1</b>
<b>40 MAINTENANCE STANDARD .....</b>	<b>40-1</b>