

# SHOP MANUAL

## **KOMATSU**

### **PC20-6**

### **PC30-6**

### **PC40-6**

MACHINE MODEL	SERIAL No.
<b>PC20-6</b>	<b>24001 and up</b>
<b>PC30-6</b>	<b>10001 and up</b>
<b>PC40-6</b>	<b>10001 and up</b>

This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.

# CONTENTS

	No. of page
<b>10 STRUCTURE AND FUNCTION</b> .....	10-1
<b>20 TESTING AND ADJUSTING</b> .....	20-1
<b>30 DISASSEMBLY AND ASSEMBLY</b> .....	30-1
<b>40 MAINTENANCE STANDARD</b> .....	40-1

020R06