

Shop Manual

HYDRAULIC
EXCAVATOR

PC4000E-6

Serial Number 08165 and up

KOMATSU

CONTENTS

2.1	SAFETY INFORMATION	2-3
2.2	OVERVIEW.....	2-4
2.2.1	NORMAL OPERATIONS	2-4
2.2.2	REGULAR MAINTENANCE.....	2-4
2.2.3	TROUBLESHOOTING, ADJUSTMENTS AND REPAIR	2-4
2.2.4	ADDITIONAL SAFETY PRECAUTIONS FOR ASSEMBLING, DISASSEMBLING AND TRANSPORTATION OF THE EXCAVATOR.....	2-4
2.3	SOUND PRESSURE LEVEL IN THE OPERATOR'S CAB.	2-5
2.4	GENERAL PRECAUTIONS COMMON TO OPERATION ON THE EXCAVATOR.....	2-6
2.4.1	UNDERSTANDING THE MACHINE	2-6
2.4.2	PRECAUTIONS BEFORE STARTING OPERATION ON THE EXCAVATOR	2-6
2.4.2.1	ENSURING SAFE OPERATION.....	2-6
2.4.3	PREPARATIONS FOR SAFE OPERATION.....	2-6
2.4.3.1	PRECAUTIONS REGARDING SAFETY RELATED EQUIPMENT.....	2-6
2.4.3.2	INSPECTING THE MACHINE.....	2-6
2.4.3.3	WEAR WELL FITTING CLOTHES AND PROTECTIVE EQUIPMENT.....	2-7
2.4.3.4	KEEP MACHINE CLEAN	2-7
2.4.3.5	PRECAUTIONS INSIDE OPERATOR'S COMPARTMENT	2-7
2.4.3.6	PROVIDE FIRE EXTINGUISHER AND FIRST AID KIT	2-8
2.4.3.7	IF A PROBLEM IS FOUND.....	2-8
2.4.4	FIRE PREVENTION.....	2-8
2.4.4.1	PRECAUTIONS TO PREVENT FIRE	2-8
2.4.4.2	ACTION IF FIRE OCCURS.....	2-9
2.4.4.3	EMERGENCY EXIT FROM OPERATOR'S CAB.....	2-10
2.4.5	PRECAUTIONS WHEN CLEANING CAB GLASS	2-10
2.4.6	PRECAUTIONS WHEN GETTING ON OR OFF THE MACHINE	2-10
2.4.6.1	USE HANDRAILS AND STEPS WHEN GETTING ON OR OFF THE MACHINE.....	2-10
2.4.6.2	NO JUMPING ON OR OFF THE MACHINE	2-10
2.4.6.3	NO PEOPLE ON THE ATTACHMENT	2-10
2.4.6.4	WORKING IN HIGH PLACES	2-10
2.4.6.5	LEAVING OPERATOR'S SEAT WITH LOCK.....	2-11
2.4.6.6	LEAVING THE MACHINE	2-11
2.4.7	BURN PREVENTION.....	2-11
2.4.7.1	HOT COOLANT	2-11
2.4.7.2	HOT OIL	2-12
2.4.8	PRECAUTIONS RELATED TO PROTECTIVE STRUCTURES	2-12
2.4.8.1	UNAUTHORIZED MODIFICATION.....	2-12
2.4.9	PRECAUTIONS AT JOBSITE.....	2-14
2.4.9.1	VISIBILITY FROM OPERATOR'S SEAT	2-15
2.4.9.2	CAMERA SYSTEM WITH MONITORS.....	2-15
2.4.9.3	ENSURE GOOD VISIBILITY.....	2-15
2.4.9.4	CHECKING SIGNS AND SIGNALMAN'S SIGNALS.....	2-15
2.4.9.5	INVESTIGATE AND CONFIRM JOBSITE CONDITIONS.....	2-16
2.4.9.6	DO NOT GO CLOSE TO HIGH VOLTAGE CABLES	2-16
2.4.9.7	WORKING ON LOOSE GROUND	2-17
2.4.9.8	GAS, DUST, STEAM AND SMOKE	2-17
2.4.9.9	VENTILATION OF ENCLOSED AREAS.....	2-18