

Operation & Maintenance Manual

SEAM020S0703

PC25-1, PC30-7 PC40-7, PC45-1 HYDRAULIC EXCAVATOR

SERIAL NUMBERS

PC25	: 1001	
PC30	: 18001	and up
PC40	: 18001	
PC45	: 1001	

 **WARNING**

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come in contact with it.

KOMATSU

CONTENTS

OPERATION

GENERAL LOCATIONS AND SPECIFICATIONS	4
INSTRUMENTS AND CONTROLS	8
CHECK BEFORE STARTING	36
OPERATING YOUR MACHINE	42
REMOVAL AND INSTALLATION OF BUCKET	64
SELECTION OF TRACK SHOES (STEEL SHOES ONLY)	70
HANDLING RUBBER SHOES (RUBBER SHOES ONLY)	72
COLD WEATHER OPERATION	80

MAINTENANCE

PERIODIC MAINTENANCE	85
PERIODICAL REPLACEMENT OF SAFETY PARTS	86
MAINTENANCE TABLE	90
OIL FILLER AND LEVEL GAUGE POSITIONS	94
EVERY 100 HOURS SERVICE	96
EVERY 250 HOURS SERVICE	98
EVERY 500 HOURS SERVICE	104
EVERY 1000 HOURS SERVICE	106
EVERY 2000 HOURS SERVICE	108
WHEN REQUIRED	110
SERVICE METER	130
MACHINE AND ENGINE SERIAL NUMBERS	132
FUEL, COOLANT AND LUBRICANTS	134
MACHINES READY FOR ATTACHMENTS	137