

# SHOP MANUAL

## **KOMATSU**

# **PC400, 400LC-7**

# **PC450, 450LC-7**

MACHINE MODEL	SERIAL No.
<b>PC400-7</b>	<b>50001 and up</b>
<b>PC400LC-7</b>	<b>50001 and up</b>
<b>PC450-7</b>	<b>20001 and up</b>
<b>PC450LC-7</b>	<b>20001 and up</b>

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- PC400, 400LC, PC450, 450LC-7 mount the SAA6D125E-3 engine.  
For details of the engine, see the 125-3 Series Engine Shop Manual.

# CONTENTS

	No. of page
<b>01 GENERAL</b> .....	01-1
<b>10 STRUCTURE, FUNCTION AND MAINTENANCE STANDARD</b> .....	10-1
<b>20 TESTING AND ADJUSTING</b> .....	To be issued next time
<b>30 DISASSEMBLY AND ASSEMBLY</b> .....	To be issued next time
<b>90 OTHERS</b> .....	90-1