# SITOP

# 

# KOMATSU PC750-6 PC800-6

MACHINE MODEL SERIAL NUMBER

PC750-6 10001 and up
PC750SE-6 10001 and up
PC750LC-6 10001 and up
PC800-6 30001 and up
PC800SE-6 30001 and up

- This shop manual may contain attachments and optional equipment that are not available
  in your area. Please consult your local Komatsu distributor for those items you may
  require. Materials and specifications are subject to change without notice.
- PC750, 800-6 mount the SAA6D140-2 engine.
   For details of the engine, see the 6D140-2 Series Engine Shop Manual.

## 20906

### **CONTENTS**

		No. of pag
01	GENERAL	. 01-1
10	STRUCTURE AND FUNCTION	. 10-1
20	TESTING AND ADJUSTING	<b>.</b> 20-1
30	DISASSENBLY AND ASSEMBLY	<b>.</b> 30-1
40	MAINTENANCE STANDARD	<b>.</b> 40-1
90	OTHERS	<b>.</b> 90-1