

SHOP MANUAL

KOMATSU

PW05-1

MACHINE MODEL	SERIAL No.
PW05-1	1001 and up

CONTENTS

	No. of page
10 STRUCTURE AND FUNCTION	10-1
20 TESTING AND ADJUSTING	20-1
30 DISASSEMBLY AND ASSEMBLY	30-1
40 MAINTENANCE STANDARD	40-1

020L01