



PW148-8

MACHINE MODEL

PW148-8

SERIAL NUMBER

H50051 AND UP

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require.
- Materials and specifications are subject to change without notice.
- PW148-8 mount the SAA4D107E-1 engine.
- For details of the engine, see the 107 Series Engine Shop Manual.

CONTENTS

No. of page

00	FOREWORD	00-1
01	GENERAL	01-1
10	STRUCTURE, FUNCTION AND MAINTENANCE STANDARD.....	10-1
20	TESTING AND ADJUSTING.....	20-1
20	TESTING AND ADJUSTING.....	20-101
20	TESTING AND ADJUSTING Troubleshooting	20-221
20	TESTING AND ADJUSTING Troubleshooting when failure code is indicated	20-301
20	TESTING AND ADJUSTING Troubleshooting of electrical system (E-Mode)	20-521
20	TESTING AND ADJUSTING Troubleshooting of electrical system (Error Checking of items without Monitor codes) ...	20-601
20	TESTING AND ADJUSTING Troubleshooting of hydraulic and mechanical system (H-Mode).....	20-711
30	DISASSEMBLY AND ASSEMBLY.....	30-1
90	OTHER	90-1