

Operation & Maintenance Manual

PC750-6 PC750LC-6 PC750SE-6

HYDRAULIC EXCAVATOR

SERIAL NUMBERS PC750-6 - 10001 and up
SERIAL NUMBERS PC750LC-6 - 10001 and up
SERIAL NUMBERS PC750SE-6 - 10001 and up

This material is proprietary to Komatsu America International Company and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu America International Company.

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or add improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, periodic revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.

5. CONTENTS

1. Foreword	0- 1
2. Safety information	0- 2
3. Introduction	0- 3
4. Location of plates, table to enter serial No. and distributor	0- 4

SAFETY

6. General precautions	1- 2
7. Precautions during operation	1- 9
7.1 Before starting engine	1- 9
7.2 After starting engine	1-11
7.3 Transportation	1-18
7.4 Battery	1-19
7.5 Towing	1-21
7.6 Lifting operations	1-21
8. Precautions for maintenance	1-22
8.1 Before carrying out maintenance	1-22
8.2 During maintenance	1-26
9. Position for attaching safety labels	1-31

OPERATION

10. General view	2- 2
10.1 General view of machine	2- 2
10.2 General view of controls and gauges	2- 3
11. Explanation of components	2- 4
11.1 Machine monitor	2- 4
11.2 Switches	2-15
11.3 Control levers, pedals	2-20
11.4 Ceiling window	2-23
11.5 Front window	2-24
11.6 Door lock	2-26
11.7 Cap, cover with lock	2-27
11.8 Hot and cool box	2-28
11.9 Luggage box	2-28
11.10 Ashtray	2-28
11.11 Handling air conditioner	2-29
11.12 Car radio	2-32
11.13 Power supply socket	2-36
11.14 Fuse	2-37
11.15 Fusible link	2-38
11.16 Controllers	2-38
11.17 Tool holder (cloth bag)	2-38
11.18 Handling grease pump	2-38
11.19 Handling accumulator	2-41

12. Operation	2-43
12.1 Check before starting engine	2-43
12.2 Starting engine	2-53
12.3 Operations and checks after starting engine	2-56
12.4 Moving machine off	2-62
12.5 Steering machine	2-65
12.6 Stopping machine	2-67
12.7 Swinging	2-68
12.8 Operation of work equipment	2-69
12.9 Handling working mode	2-70
12.10 Prohibitions for operation	2-71
12.11 Precautions for operation	2-73
12.12 Precautions when traveling up or down hills	2-74
12.13 How to escape from mud	2-76
12.14 Work possible using hydraulic excavator	2-77
12.15 Replacement of bucket	2-78
12.16 Parking machine	2-79
12.17 Check after finishing work	2-80
12.18 Stopping engine	2-81
12.19 Check after stopping engine	2-82
12.20 Locking	2-82
13. Transportation	2-83
13.1 Loading, unloading work	2-83
13.2 Precautions for loading	2-85
13.3 Precautions for transportation	2-85
13.4 Transportation posture	2-86
13.5 Procedure for increasing or reducing track frame gauge	2-91
14. Cold weather operation	2-93
14.1 Precautions for low temperature	2-93
14.2 Precautions after completion of work	2-95
14.3 After cold weather	2-95
15. Long-term storage	2-96
15.1 Before storage	2-96
15.2 During storage	2-97
15.3 After storage	2-97
15.4 Starting machine after long-term storage	2-97
16. Troubleshooting	2-98
16.1 Phenomena that are not failures	2-98
16.2 Method of towing machine	2-98
16.3 Precautions on particular jobsites	2-98
16.4 If battery is discharged	2-99
16.5 Other trouble	2-103