

# HYDRAULIC EXCAVATOR

**PC1250-8**  
**PC1250SP-8**  
**PC1250LC-8**

Machine model	Serial number
---------------	---------------

PC1250-8	30001 and up
PC1250SP-8	30001 and up
PC1250LC-8	30001 and up

---

## 00 Index and foreword

### Index

---

---

Composition of shop manual .....	2
Table of contents .....	4

## Table of contents

00 Index and foreword	
Index	SEN00891-19
Composition of shop manual .....	2
Table of contents.....	4
Foreword and general information	SEN00892-04
Safety notice .....	2
How to read the shop manual.....	7
Explanation of terms for maintenance standard .....	9
Handling of electric equipment and hydraulic component .....	11
Handling of connectors newly used for engines .....	20
How to read electric wire code.....	23
Precautions when carrying out operation .....	26
Method of disassembling and connecting push-pull type coupler .....	29
Standard tightening torque table.....	32
Conversion table.....	36
01 Specification	
Specification and technical data	SEN00894-02
Backhoe specification .....	2
Loading shovel specification.....	4
Specifications.....	6
Weight table .....	22
Table of fuel, coolant and lubricants .....	30
10 Structure, function and maintenance standard	
Engine and cooling system	SEN00896-01
PTO .....	2
PTO lubrication system.....	4
Radiator and oil cooler.....	6
Power train	SEN00897-01
Power train.....	2
Swing machinery .....	4
Swing circle.....	8
Final drive .....	9
Sprocket.....	12
Undercarriage and frame	SEN00898-01
Track frame, recoil spring .....	2
Idler.....	4
Carrier roller.....	6
Track roller .....	7
Track shoe .....	8
Air system	SEN00899-00
Air piping drawing .....	2
Air circuit diagram .....	3
Air governor .....	4
Air tank.....	5
Safety valve .....	6
Horn valve.....	7
Grease pump .....	8

Hydraulic system, Part 1	SEN00900-01
Hydraulic piping drawing .....	2
Hydraulic tank .....	5
Hydraulic pump .....	7
Line oil filter .....	48
Pilot oil filter .....	49
Return oil filter .....	50
Drain oil filter .....	51
Cooling fan pump .....	52
Cooling fan motor .....	66
Aftercooler fan motor .....	72
Hydraulic system, Part 2	SEN00901-02
Control valve .....	2
Swing motor .....	17
Center swivel joint .....	26
Travel motor .....	27
PPC control relief valve .....	37
Accumulator .....	38
Valve control .....	39
PPC valve .....	40
Solenoid valve .....	50
Hydraulic cylinder .....	58
Work equipment	SEN00902-00
Work equipment .....	2
Dimensions of work equipment .....	6
Cab and its attachments	SEN00903-00
Air conditioner .....	2
Electrical system	SEN00904-05
Engine control .....	2
Electric control system .....	9
Monitor system .....	45
Sensor .....	68
20 Standard value table	
Standard service value table	SEN01631-04
Standard value table for engine related parts .....	2
Standard value table for chassis related parts .....	3
30 Testing and adjusting	
Testing and adjusting, Part 1	SEN01632-04
Tools for testing, adjusting, and troubleshooting .....	3
Sketch of special tool .....	8
Testing engine speed .....	9
Testing air supply pressure (Boost pressure) .....	10
Testing exhaust temperature .....	11
Testing exhaust color .....	12
Testing and adjusting valve clearance .....	14
Testing compression pressure .....	16
Testing blow-by pressure .....	19
Testing engine oil pressure .....	20
Testing EGR valve and bypass valve drive oil pressure .....	21
Adjusting engine speed sensor .....	23
Handling fuel system parts .....	24
Releasing residual pressure in fuel system .....	24
Testing fuel pressure .....	25
Testing fuel return rate and fuel leakage .....	26
Bleeding air from fuel circuit .....	29