

HYDRAULIC EXCAVATOR

PC210-8

PC240LC-8

PC210LC-8

PC240NLC-8

PC210NLC-8

PC230NHD-8

Machine model	Serial number
----------------------	----------------------

PC210-8	K50001 and up
PC210LC-8	K50001 and up
PC210NLC-8	K50001 and up
PC230NHD-8	K50001 and up
PC240LC-8	K50001 and up
PC240NLC-8	K50001 and up

00 Index and foreword

Index

Organization list of the shop manual	2
Table of contents	4

Table of contents

00 Index and foreword	
Index	UEN00093-07
Organization list of the shop manual	2
Table of contents.....	4
Foreword and general information	UEN00094-00
Foreword and general information	2
Safety notice	2
How to read the shop manual	6
Explanation of terms for maintenance standard	8
Handling electric equipment and hydraulic component	10
How to read electric wire code.....	18
Method of disassembling and connecting push-pull type coupler	21
Standard tightening torque table.....	24
Conversion table.....	28
01 Specification	
Specification and technical data	UEN00095-02
Specification and technical data	2
Specification dimension drawings.....	2
Working range diagram	3
Specifications.....	4
Weight table	8
Table of fuel, coolant and lubricants	12
10 Structure, function and maintenance standard	
Engine and cooling system	UEN00096-01
Engine and cooling system	2
Engine related parts.....	2
Radiator, oil cooler, aftercooler and fuel cooler.....	3
Diesel Particulate Filter	4
Diesel Particulate Filter - Component Parts.....	5
System Description.....	6
Regeneration	6
Power train	UEN00097-00
Power train	2
Power train.....	2
Final drive	4
Swing machinery	6
Swing circle.....	10
Undercarriage and frame	UEN00098-00
Undercarriage and frame	2
Track frame and recoil spring	2
Idler.....	4
Carrier roller.....	6
Track roller	7
Track shoe	8
Hydraulic system, Part 1	UEN00099-01
Hydraulic system, Part 1	2
Hydraulic equipment layout drawing.....	2
Hydraulic tank and filter	4
Hydraulic pump.....	5
Hydraulic pump.....	6
Pilot oil filter	29